

RS232 command set to drive buzzer/LED

1. Enable RS232 Command Set Control: (For 19200,n,8,1 Only)

RS232 LED/Buzzer command set frame as below:

STX	J	NUMBER (0~9)	CR
02h	4Ah	30h~39h	0Dh

OR

STX	Addr.	Func	Len	NUMBER (0~9)	CRC16
01h	1Byte	3Ch	01h	30h~39h	2Bytes

*refer to GNETPLUS protocol

Command Table:

NUMBER	Descriptions
0 (30h)	All LED Off, Buzzer Off
1 (31h)	Green LED ON
2 (32h)	Green LED OFF
3 (33h)	Red LED ON
4 (34h)	Red LED OFF
5 (35h)	Buzzer Beep 1 Time
6 (36h)	Buzzer Beep 3 Time
7 (37h)	Green LED ON with Beep 1 Time
8 (38h)	Red LED ON with Beep 3 Time
9 (39h)	All LED ON (Orange)