




MS5145 USB FR


Enter/Exit Configuration Mode



Recall Defaults



* **Enable USB Keyboard Emulation Mode**



France Keyboard

Enter/Exit Configuration Mode

